



AFTERCARE GUIDE

Professional care for lasting
clarity, finish and performance.

For INOZETEK vinyl Vinyl, PPF, and DPPF



FIRST

14 Days

No washing, high-pressure
spray or automatic car washes.

REGULAR CARE

2-3 WKS

Wash using pH-neutral shampoo
and soft microfiber towels.

PROTECTION

3-6 MTHS

Refresh with recommended
ceramic spray or sealant.

THE ESSENTIALS

1 START RIGHT

Allow the film to cure. During the first 14 days, avoid washing, high-pressure sprays and automatic car washes. If necessary, gently dust with a clean microfiber towel.

2 WASH SMART

Wash every 2–3 weeks with a pH-neutral shampoo and the two-bucket method. Rinse thoroughly and dry with soft microfiber towels to avoid streaks, spots and scratches.

3 REMOVE PROMPTLY

Bird droppings, bug splatter and chemical spills should be rinsed or washed away immediately. Prompt removal helps prevent staining and preserves clarity.

4 BOOST PROTECTION

Every 3–6 months, apply an INOZETEK-recommended ceramic spray or sealant after washing. For a deeper refresh, book a maintenance wash with your certified installer.

WHAT TO AVOID



HIGH-PRESSURE
WASHERS



AUTOMATIC
CAR WASHES



DIRECT
SUNLIGHT



HARSH/CAUSTIC
CHEMICALS



SCAN FOR THE FULL
AFTERCARE GUIDE

Follow the full guide to help protect your finish
and support long-term performance.

BUILT FOR INSTALLERS.
TRUSTED BY PROFESSIONALS.